

# Setup Guide for Anoto Dot Pattern Printing on Oki C9600

## Configuring the Oki C9600 and Anoto FDT



In order to print documents that adhere to Anoto qualified printing requirements, you must ensure that the Oki C9600 printer is correctly configured and that the Anoto Forms Design Tool (FDT) is configured to generate C9600 printer specific PostScript files. Both steps are required and described in this document:

- A. Configuring the C9600 Printer
- B. Configuring the Anoto FDT for the C9600 printer

### A. Configuring the C9600 Printer


To configure the C9600, the CMYK Conversion setting must be set to the "OFF" position. To make this setting, go to the operator panel located on the front of the printer and follow the steps below.




1) While the printer is turned on, press **MENU UP**  once. Press **MENU DOWN**  several times until **Admin Setup** menu is highlighted. Press **ENTER**.

2) Enter your admin password to access this menu. Default password is 0000. Numbers are selected by pressing the up arrow key  followed by the **ENTER** key. Repeat 4 times


3) When correct password is displayed, press **ENTER**.

4) Once in the admin menu, press the down arrow key  several times to highlight the "**Color Setup**" menu and press **ENTER**.

4) Press  several times to highlight the "**CMYK Conversion**" menu and press **ENTER**.

5) If CMYK conversion is set to "**ON**" press  and then **ENTER** to set it to "**OFF**".

Note: The asterisk displayed indicates whether the current setting is On or OFF

6) Press  several times to go back to the ready status. The process is now complete.

## B. Configuring the Anoto FDT for the C9600 printer

When using the Anoto Forms Design Tool (FDT), you need to set specific parameters to optimize the PostScript file generated to the printer of choice. This is done by installing and selecting a printer specific Printer Profile (.txt file) within the FDT. You must use the printer profile when generating PostScript files from the FDT to adhere to the Anoto qualified printing requirements.

The printer profile allows you to set the same parameter values as were defined and used when the printer was originally tested and qualified by Oki and Anoto thus ensuring the high quality of printed Anoto dot patterns and correct color separation for each qualified printer.


Many different printer profiles can be stored within the FDT.

### To Download, Install, and Select Oki Printer Profiles for PostScript file generation:

1. Download the correct Oki Printer Profile from the Anoto web site  
<http://partner.anoto.com/cldoc/15837.htm>

**Note:** There are two Printer Profiles for the Oki C9600. Use the *Oki C9600 PS-form off* profile if you do not intend to use the PostScript Forms option. The PostScript Forms option is described on the next page.

2. Rename the profile to *Oki C9600 PS-form off.txt*, and save it to the Anoto FDT's printer Settings Folder, which should be located at:  
C:\Program Files\Adobe\Acrobat 6.0\Acrobat\plug\_ins\Anoto\FDT\printersettings
3. Make sure you have restarted Adobe Acrobat. Then select "Generate Postscript Files" from Acrobat's Anoto menu. You will see the following dialog box after naming the PostScript file and then clicking "Save":



4. Select the appropriate Printer Profile from the drop-down menu and click OK. As mentioned above, there are two C9600 profiles available from the Anoto website for the C9600 printer. You should use the *Oki C9600 PS-form off* profile unless you decide to use the PostScript Forms option described in the next section.

For a detailed description of Printer Profiles, please see Section 6.0 of the Anoto Forms Design Tool User Guide.

## ***Optional: Using the Anoto FDT PostScript Forms Option***

In situations where a large number of pages of the same form are being printed with Anoto's so called Unique dot pattern on each page, the PostScript Forms option may be used to reduce the size of the PostScript files generated.

For the Oki C9600 printer, a Hard Drive must be installed to use the PostScript Forms option.

To use the PostScript Forms option, download the *OKI C9600 ps-form on* Printer Profile from the Anoto website and follow the instructions on the previous page substituting *the OKI C9600 ps-form off* profile for the *OKI C9600 ps-form on* profile. The profile will make all of the necessary settings for you in the FDT automatically.

